

IMPORTANT! INSTALLATION INSTRUCTIONS
READ BEFORE DRILLING HOLES IN THE TRACK.



WARNING

woody's[®]

2.86 pitch - Single ply track TEMPLATE (286S-TEMP-3)



WARNING Review the snowmobile or track manufacturer's studding recommendations in your owner's manual. You may void your warranty if their recommendations are not followed. You must read and understand these instructions before drilling holes in your track, if you have any questions contact Woody's through the methods listed at the bottom of the page. Always confirm the allowable clearance between the track and the tunnel and/or heat exchangers. Verify that your sled has proper tunnel protection. Do not install studs under the tunnel protector strips. The integrity of the tunnel protectors is vital and must not be subjected to possible damage. Inspect the track- Never drill holes or install studs in a damaged or deteriorating track. This template is for single ply tracks with a 2.86 pitch and should not be used on any other tracks. The 2.86 pitch single ply track can only be studded using Woody's[®] Grand Master[®] studs and Woody's[®] Grand Digger[®] support plates. **Using any other stud or support plate could cause damage to your track.** If you do not know the pitch of the track on your snowmobile, contact your snowmobile dealer.

The patterns on this template contain specific stud amounts. Determine which amount of studs applies to your model snowmobile and riding style. Choose a pattern to accommodate that exact number of studs. Familiarize yourself with the pattern by referring to the picture on the 286S-TEMP-3 Template.

Refer to the picture on the Woody's[®] 286S-TEMP-3 Template. Note, the pattern you have chosen has a specific sequence of letters, do not deviate from this sequence.

Note: **A PITCH** is the space between each lug row.

- 1) This template will accommodate 14", 15" & 16" wide tracks. At the ends of each lug slot there are two outlined orange gradient portions.
 - To fit a 14" (356mm) wide track leave the outlined orange areas intact.
 - To fit a 15" (381mm) wide track remove the orange portion designated 15" by cutting along the dashed lines.
 - To fit a 16" (406mm) wide track remove the orange portions designated 15" & 16" by cutting along the dashed lines.If the outlined orange areas have been removed, the modified template should not be used on track widths less than the modified width.
- 2) Your 2.86 pitch - single ply track could be pre-dimpled for placement of 2 studs per lug. The dimples indicate stud placement.
- 3) To expand the pre-dimpled pattern from 2 studs per lug to 3 studs per lug, you will need to mark the letters for one of the other patterns. Remove the pre-punched knockouts adjacent to the letters of your chosen pattern.
- 4) You must start the pattern by lining up the template over the 2 studs per lug pre-dimpled location marks. Keep moving the template until the holes marked with A line up with the dimples. Place the template on the track. This template will cover 6 pitches with the lugs protruding through. The template will follow the rotation of the track.
- 5) Begin marking, with a Woody's[®] Track Marker, the letters that correspond with the pattern of your choice. (The extended pattern marks will include the pre-dimpled pattern.)
- 6) Move the template to cover the next 6 pitches: You will mark the pattern a total of 7 times for a 120" (3051mm) track, 7.5 times for a 129" (3269) track, 8 times for a 137" (3487mm) track, 8.5 times for a 146" (3705mm) track, and 9 times for a 154" (3923mm) track.
- 7) **IMPORTANT** Confirm before drilling that you have marked ONLY the holes adjacent to the letter that applies to your pattern. The support plate must lay flat in the pitch. Confirm each support plate lays flat in the pitch. Check the entire track.
- 8) Using a Woody's[®] Track Drill, Part# DRIL-UNIV, drill the marked holes.
IMPORTANT Check to make sure you will only drill through the track. It is essential not to let the drill touch the idler wheels or any other component of the snowmobile.
- 9) Inspect the track for any plugs that are still attached to the track. Remove the plugs.
- 10) Begin installing a stud in each hole drilled. Refer to the installation instructions included in the stud package.
 - a. Read and follow the direction in your snowmobile owners' manual on track studding and maintenance.
 - b. The addition of studs may effect your track warranty.
 - c. Studding may effect track longevity.
 - d. Never drill holes in or stud a damaged or deteriorating snowmobile track.

www.woodystraction.com • E-mail: woodys@wiem.com

IMPORTANT! INSTALLATION INSTRUCTIONS
READ BEFORE DRILLING HOLES IN THE TRACK.

**IMPORTANT! INSTALLATION INSTRUCTIONS
READ BEFORE DRILLING HOLES IN THE TRACK.**

**2.86 pitch - Single ply track
TEMPLATE
(286S-TEMP-3)**

For single ply tracks only.